

SPEED LIMIT SETTING

1. Please open the case (and do not switch off the speed sign)
2. You will find a big red push-button inside and please push the push-button and the speed limit setting will run automatically from 15-80. As you reached the requested speed limit please do not push the push button any more.
3. After you released the limit it will be saved automatically.
4. Close back the speed sign.

